


WELCHE FEILE FÜR WELCHE KETTE



Kette	E	E:2 = Teilung	Ø Feile
1	1/2" 12.70 mm	1/4" 6.35 mm	5/32" 4.0 mm
2	.65" 16.50 mm	.325" 8.25 mm	11/64" - 3/16" 4.5 - 4.8 mm
3	3/4" 18.64 mm	3/8" low profile 9.32 mm	5/32" 4.0 mm
4	3/4" 18.64 mm	3/8" 9.32 mm	13/64" - 7/32" 5.2 - 5.5 mm
5	.808" 20.52 mm	.404" 10.26 mm	7/32" 5.5 mm
6	1.5" 38.10 mm	3/4" (Harvester) 19.05 mm	5/16" 7.9 mm



Teilung = E:2

Legen Sie Ihre Kette auf die Zeichnung, um die Teilung Ihrer Kette zu bestimmen. Skala 1/1

